



### To Connect the TriggerGrip Unit:

1. Wear safety glasses.
2. Remove the plastic tab from the top of the aerosol can and ensure the TriggerGrip™ adapter toggle switch is in the “Off” position.
3. Hold the aerosol can vertically and attach the front mounting pins of the adapter to the plastic shroud, pushing down to secure with a “click” sound.
4. Confirm a snug fit by gently pulling up on the adapter and check that the toggle switch is still in the “Off” position.
5. Insert the silver TriggerGrip hose into the valve opening, pushing it tight while keeping your thumb under the black trigger.
6. Attach the longer section of the TriggerGrip clip to the adapter by inserting the pin on the right side, sliding down until engaged, then repeat on the left side.
7. Your benchtop cleaning system is ready. Switch the toggle switch to “On” for dispensing solvent. Remember to switch it to “Off” when not in use.

### To Disconnect the TriggerGrip Unit:

1. Wear safety glasses.
2. Ensure the toggle switch is in the “Off” position.
3. Purge any remaining solvent by pressing the trigger on the TriggerGrip. Empty solvent into a MicroCare lint-free wipe and discard.
4. Squeeze both sides of the TriggerGrip clip to disengage from mounting holes. Slide the clip away.
5. Pull the silver TriggerGrip hose from the valve opening and gently remove the TriggerGrip adapter from the aerosol can shroud.

*Newly designed TriggerGrip adapter provides easier, more secure connectivity for your MicroCare™ TriggerGrip™ PCB Cleaning Tool.*



SCAN ME



**MicroCare, LLC**  
595 John Downey Drive  
New Britain, CT 06051 USA  
Tel: +1 860 827 0626  
Toll Free: 1 800 638 0125  
Email: TechSupport@MicroCare.com

**MicroCare U.K. Ltd**  
Unit 4, Whitehall Court  
Leeds  
LS12 5SN UK  
Tel: +44 (0) 113 3609019  
Email: MCCEurope@MicroCare.com

**MicroCare Asia Pte Ltd**  
102E, Pasir Panjang Road  
Citilink, #05-06  
Singapore 118529  
Tel: +65 6271 0182  
Email: TechSupport@MicroCare.sg



For more information and to download SDS visit our website  
**MicroCare.com**